Quick guide 3M PELTOR WS ProTac XPI

|		
Turn headset on & off	Hold the ON/OFF/Mode button for 1 s — *"Power on"* — **1 sec**	Hold the ON/OFF/Mode button for 2 s — *"Power off"* — **2 sec**
Volume on the ambient listening	*"Ambient listening"* Push ON/OFF/Menu until the ghost voice confirm "Ambient listening"	Push + or – to adjust the ambient listening
Volume on Bluetooth® connected cell phone	*"Phone volume"* Push ON/OFF/Menu until the ghost voice confirm "Phone volume"	Push + or – to adjust the Phone volume
Streaming volume on Bluetooth® connected cell phone	*"Streaming volume"* Push ON/OFF/Menu until the ghost voice confirm "Streaming volume"	Push + or – to adjust the music volume
Volume on Bluetooth® connected two-way radio	*"Bluetooth radio volume"* Push ON/OFF/Menu until the ghost voice confirm "Bluetooth radio volume"	Push + or – to adjust the Bluetooth radio volume
Activate Push-To-Listen	Push ON/OFF/Menu twice to activate "Push-To-Listen"	Push button of your choice ones to deactivate "Push-To-Listen"

3M

Change settings in the menu

"Menu"

Hold the + & - buttons for 1 s

1 sec

Connect cell phone or two-way radio via Bluetooth®

"Bluetooth pairing"

Push ON/OFF/Menu until the ghost voice confirm "Bluetooth pairing"

Push + to start pairing your Bluetooth device

Voice operated transmission on two-way radio via Bluetooth®

"VOX"

Push ON/OFF/Menu until the ghost voice confirm "VOX"

Push + or – to choose vox on or off

Adjust battery type

"Battery type"

Push ON/OFF/Menu until the ghost voice confirm "Battery type"

Push + or – to choose rechargable or alkaline battery

Reset to factory default

"Reset"

Push ON/OFF/Menu until the ghost voice confirm "reset"

Hold + button for 2 sec to confirm

3M

Change settings in the setup menu	**2 sec** · *"Power on setup mode"* · Headset in off mode; Hold ON/OFF/Menu & answering button for two seconds.	**1 sec** · *"Menu"* · Hold the + & - buttons for 1 s
Deactivate vox in meny	*"Vox mode"* · Push ON/OFF/Menu until the ghost voice confirm "Vox mode"	Push + or – to choose vox on or off
Automatic power off	*"Automatic power off"* · Push ON/OFF/Menu until the ghost voice confirm "Automatic power off"	Push + or – to choose on or off
Activate Bluetooth® streaming	*"Bluetooth streaming"* · Push ON/OFF/Menu until the ghost voice confirm "Bluetooth streaming"	Push + or – to choose on or off
Activate Bluetooth® Multipoint	*"Bluetooth Multipoint"* · Push ON/OFF/Menu until the ghost voice confirm "Bluetooth Multipoint"	Push + or – to choose on or off. Push menu button to confirm.
Adjust the gain on the microphone	*"Microphone volume"* · Push ON/OFF/Menu until the ghost voice confirm "microphone volume"	Push + or – to choose: Off/Low/Medium/High
Deacivate LED	*"LED"* · Push ON/OFF/Menu until the ghost voice confirm "LED"	Push + or – to choose LED-flash on or off

3M