# TECHNICAL DATA SHEET ITM WITHOUT POST

#### Checkmate Checkline II ITM Without Post

riation and

The ITM (Intermediate Bracket) is mounted onto the Adjustment Body and is used to support the 8mm wire rope. This assembly is fixed directly onto the required surface where a post assembly is not required. The bracket has the ability to be rotated through 180° and set at intervals of 30°



TDS44

CHECKMATE



### principal materials

- Adjustment Body & Intermediate
  Bracket
  Cast Stainless Steel Electro Polished
- M10 Cap Head Bolt Stainless Steel with Loctite
- Reducing Sleeve
  Nylon

#### standards

 These components form part of the Checkmate EN 795 approved system

## ordering information

Part No.	Description	Weight
PPESLL-505	ITM Bracket without TopFix Post	0.6kg

DISCLAIMER – COMPONENTS MUST BE USED AS PART OF A COMPLETE CHECKMATE CHECKLINE SLL SYSTEM, COMPRISING OF CHECKMATE COMPONENTS ONLY. STRUCTURAL ENGINEER APPROVAL IS REQUIRED BY BUILDING OWNER. SPECIFYING AND INSTALLING CHECKLINE REQUIRES TRAINING AND WRITTEN APPROVAL FROM CHECKMATE – CONTACT CHECKMATE FOR DETAILS.





www.checkmateuk.com

rds44

ISSUE

05

ITM without Post Technical Data Sheet