ZEN VISOR CE





Polycarbonate eye protection designed to work with all Zenith series helmets. EN 166 rated to protect the eyes of workers from medium level energy impacts. Attaches with Easy Click Visor Adapters.

Securely flips up and down. Available in 3 lens color options for various levels of light transmission.

TECHNICAL DETAILS



MATERIAL

Polycarbonate



STANDARD

EN 166 / ANSI Z87.1 EN170 (clear) EN172 (smoke, silver mirror)



OPTICAL CLASS



TEMPERATURE OF USE

-5°C/+55°C



WEIGHT



CATEGORY

TECHNOLOGIES



Equipped with an anti-fog treatment to increase wearer visibility when active and in a variety of conditions.

Designed with a rubber upper contour to keep out sweat moisture



PANORAMIC LENS

Wide view lens for optimal protection and visibility.



SCRATCH RESISTANT

Equipped with a scratch-resistant treatment for increased durability.



COMPATIBLE WITH GLASSES

Designed for use over corrective glasses.



CUT PROOF EDGE

and to enhance comfort.

DRIP PROOF UPPER CONTOUR

Designed with a cut proof edge for enhanced comfort and safety.



EASY CLICK VISOR ADAPTERS

Attaches visors or face shields to helmet.

MARKINGS

| CODE | COLOR | MARKING |
|--------------|---------------|------------------------------------------------------------------------------|
| WVI00007-500 | CLEAR | ZEN YY/MM CE 2C-1,2 KASK 1BTKN EN 166BT ANSI Z87+ U6 X D3 |
| WVI00007-510 | SMOKE | ZEN YY/MM CE 5-1,4 KASK 1BTKN EN 166BT ANSI Z87 + U6 L1.5 X D3 |
| WVI00007-520 | SILVER MIRROR | ZEN YY/MM CE 5-1,4 KASK 1BTKN EN 166BT ANSI Z87 + U6 L2.5 X D3 |

ADDITIONAL INFORMATION

GUARANTEE

3 years starting from the date of purchase.

YEARS

SHELF LIFE

10 years starting from the date of manufacture. Shelf life depends on various factors that can cause deterioration such as sudden temperature changes, the amount of exposure to direct sunlight and the intensity of use. Altered vision and scratches are elements that signal the need to check for deterioration of the visor.

Clean only with water and mild soap. Allow to air dry. Do not use chemical detergents, solvents, petrol powders as they are too aggressive and could lower the structural resistance of the visor. Do not rub the lens when dry.

ZEN VISOR COLLECTION



WVI00007-500

ZEN VISOR CLEAR



WVI00007-510 ZEN VISOR SMOKE



WVI00007-520 ZEN VISOR SILVER MIRROR



WKI00002-500 KIT ZEN VISOR CLEAR



WAC00009 ADAPTERS

DISCOVER MORE















